locus. We could add integral or lag compensation for steady-state error performance and vary the gain for transient response performance. But what if we desire $\quad ^{\it O}$ closed-loop poles $p_{1,2}$ to be in a location that the root locus does not intersect? Among many possible methods to address this, we pursue the following: a derivative compensator with zero location z_c chosen such that the root locus intersects $p_{1,2}$, with form $K(s-z_c)$, where $K \in \mathbb{R}$ is a gain. This compensator is called "derivative" because its primary effect on the overall controller's operation on the error e is a new factor of s, yielding a scaling of the term $sE(s) = \dot{e}(t)$. The effect of this zero is to pull the locus toward it. Consider the simple plant of Fig. PD.1. Suppose we would like to speed up the closed-loop response, but cannot because, no matter how much gain we use, the settling time Figure PD.1: root locus for a simple plant with two poles. is fixed by the vertical asymptotes. If we use a compensator zero at $z_{\rm c},$ we can pull the locus leftward, as shown in Fig. PD.2. Varying z_c from $-\infty$ to 0, we see that any location left of -2can be intersected. In fact, if we consider both positive and negative gains for this example, we can place a desired closed-loop pole at any location in the complex plane! A way to approach designing a controller for a plant G with a derivative compensator C is to consider the compensator zero's effect on the phase criterion, which must always be satisfied $z_c = 0$ Figure PD.2: root locus (blue) for plant with poles (red) compensated with a zero (green) at z_c . Note that varying z_c yields root loci that can intersect any point in the complex plane if negative gains are considered. An animation corresponding to this figure can be found at https://youtu.be/VZbT_2bT2xU. at points on the root locus: $\angle(G(s)C(s)) = \pi$. In order for a desired point $\boldsymbol{s}=\psi$ to be on the 3. The 2π modulo in these expressions is suppressed for clarity. root locus, then,3 4(6(4)((4))=T < (G(4)) + (((4))=T ∠(C(4)) = 1 - ∠(G(V)) $\angle (\Psi - Z_c) = A - \angle (G(\Psi))$ Let this angle $\angle(\psi-z_c)$, called the compensator angle, be given the symbol $\theta_{\rm c} \equiv \angle (\psi - z_{\rm c}).$ Then $z_{c} = \operatorname{Re}(\psi) - \operatorname{Im}(\psi) / \tan \theta_{c} \quad (\theta_{c} \in [-\pi, \pi]), \quad (4)$ where we have limited the application of this result to $\theta_c \in [-\pi,\pi]$ because a single zero can contribute angles in this interval only.^{4,5} This 4. See Lec. rldesign.multd for how to handle required angle compensations beyond $\pm\pi.$ result is to be used in the design procedure that 5. Note that $\theta_c\in[-\pi,0)$ is possible only when $\mathrm{Im}\,\psi<0$ and $\theta_c\in(0,\pi]$ is possible only when $\mathrm{Im}\,\psi>0.$ follows. It can be understood geometrically as the position of z_c such that the angle of the vector with tail at z_c and head at ψ is θ_c . Design procedure The following procedure provides a starting-point for proportional-derivative controller design. Let's assume the transient response specification is such that we desire a closed-loop pole to be located at $\underline{s} = \psi$. 1. Design a proportional controller to meet transient response requirements by choosing the gain K_1 for the dominant closed-loop poles to be as close as possible 2. Include a cascade derivative compensator of the form $K_2(s-z_c),$ where, initially, $K_2 = 1$ and z_c is a real zero that satisfies Eq. 4. For convenience, we repeat the two key formulas: $\theta_c = \pi - \angle G(\psi) \quad \text{and} \quad$ $z_c = \mathrm{Re}(\psi) - \mathrm{Im}(\psi) / \tan \theta_c \quad (\theta_c \in [-\pi, \pi]).$ 3. Use a new root locus to tune the gain K₂ such that a closed-loop pole is at $\boldsymbol{\psi}.$ 4. Construct the closed-loop transfer function with the controller $K_1K_2(s-z_c)$. 5. Simulate the time response to see if it meets specifications. Tune. A design example Let a system have plant transfer function (s+2)(s+6)(s+11)Design a PD controller such that the closed-loop settling time is about 0.8 seconds and the overshoot is about 15%. Determining ψ We use Matlab for the design.⁶ First, we must 6. See ricopic.one/control/source/pd_controller_design_example.m determine what the specified transient response for the source. criteria imply for the locations of our closed-loop poles. Let one of these desired pole locations be called $\boldsymbol{\psi}.$ The transient response performance criteria are as follows. Ts = .8; % sec ... spec settling time
OS = 15; % percent ... spec overshoot The second-order approximation from Chapter trans tells us that the settling time specification implies a specific $\mathrm{Re}(\psi)$ and the overshoot a specific angle $\angle \psi$. The real part is found from the expressions
$$\begin{split} T_s &= \frac{4}{\zeta \omega_\pi} \quad \text{and} \quad \mathrm{Re}(\psi) = -\zeta \omega_\pi \, \Rightarrow \quad (8) \\ & \mathrm{Re}(\psi) = -\frac{4}{T_s}. \end{split} \label{eq:resolvent}$$
The angle is found via the equations $\zeta = \frac{-\ln(\% \text{OS/100})}{\sqrt{\pi^2 + \ln^2(\% \text{OS/100})}},$ $\tan(\angle\psi) = \frac{\frac{\cdot}{\zeta}}{\zeta}, \quad \text{and} \quad \tan(\angle\psi) = -\operatorname{Im}(\psi)/\operatorname{Re}(\psi).$ A remarkably simple expression results:
$$\begin{split} &\mathrm{Im}(\psi) = -\operatorname{Re}(\psi) \frac{\sqrt{1-\zeta^2}}{\zeta} \\ &\mathrm{Im}(\psi) = -\operatorname{Re}(\psi) \frac{\pi}{\ln(100/\%OS)}. \end{split}$$
So, in the final analysis, the desired pole location ψ (assuming the second-order approximation is valid) is given by the expression $\psi = -\frac{4}{T_s} \left(1 - j \frac{\pi}{\ln(100/\% OS)} \right). \tag{13}$ This formula holds beyond the scope of this problem. We define it as an anonymous function. psi_fun = @(Ts,pOS) -4/Ts*(1-1j*pi/log(100/pOS));
psi = psi_fun(Ts,OS); disp(sprintf('psi = %0.3g + j %0.3g',real(psi),imag(psi))) psi = -5 + j 8.28 Figure PD.3: root locus without compensation. P control We design a proportional controller that gets us as close as possible to $\boldsymbol{\psi}.$ The root locus is shown in Figure PD.3. G = zpk([],[-2,-6,-11],1); figure rlocus(G) Although we cannot get close to $\boldsymbol{\psi}$ on the root locus, we can at least meet our %OSspecification by choosing a gain of about $K_1 = 240.$ Let's construct the compensator and corresponding closed-loop transfer function G_P for gain control. K1 = 240;
G_P = feedback(K1*G,1); Derivative compensation Now, we use cascade derivative compensation with compensator $K_2(s-z_c)$. For now, we set $K_2 = 1$. From Equation 4, we

rldesign.PD Proportional—derivative (PD) controller

design

Thus far, our designs have been restricted to closed-loop pole locations on the original root

The resulting root locus of Figure PD.4 intersects ψ ! (I mean, we knew it would, but we had our doubts.) The corresponding gain is, from Equation 2 (or we could use the data cursor),

0.8 0.6 0.6 0.4

Figure PD.5: step responses for proportional and proportional derivative controllers.

Figure PD.5: step responses for proportional and proportional derivative controllers.

in this case is questionable, due to the proximity of a third closed-loop pole. In any case, we simulate the step response to test the efficacy of the PD controller design and to compare it with the P controller.

figure
plot(t_a,y_P);
hold on;
plot(t_a,y_PD);
xlabel('time (s)');
ylabel('step response');
grid on
legend('P control','PD control','location','southeast');

The responses, shown in Figure PLag.3, suggest

t_a = linspace(0,2.5,200); % s ... sim time
y_P = step(G_P,t_a); % P controlled step response
y_PD = step(G_PD,t_a); % PD controlled step response

the PD controller is at least close to meeting the transient specifications. It is a happy accident that the steady-state error also improved; derivative compensation does not always do this. Let's use stepinfo to compute more accurate transient response characteristics of the PD-controlled system.

si_PD = stepinfo(y_PD,t_a);

settling time: 0.82 percent overshoot: 16.2

This is quite close to the specification. If desired, the gain K_2 and the zero location z_c could be tuned, iteratively.

disp(sprintf('settling time: %0.3g',si_PD.SettlingTime))
disp(sprintf('percent overshoot: %0.3g',si_PD.Overshoot))