

## Resource: 5 Preparing the myRIO

The myRIO must be connected to power and to the computer via USB. We will need to access the on-board flash memory of the myRIO from the computer. If under `Computer` in Windows Explorer no network drive `http://172.22.11.2/files` is available, it must be added. If required, map the network drive as follows.

- 1. Navigate to `Computer` in Windows Explorer.
- 2. Click (near the toolbar) `Map network drive`.
- 3. Enter the following path: `http://172.22.11.2/files`.
- 4. Check both `Reconnect at login` and `Connect using different credentials`.
- 5. Click `Finish`. Wait.
- 6. If asked for a username and password, enter the username `admin` and leave the password blank. (If you're using myRIO #4 for some reason the password also is `admin`.)
- 7. Click `Ok`. Wait.
- 8. A new network drive `http://172.22.11.2/files` should appear.
- 9. Navigate to `/c/data`. This is where your data files will appear.